


Imatges Sobel


1/4	Precision		Recall		F1-Score		Temps	
80/20	Sense HOG		Sense	Sense HOG		Sense HOG		HOG
KNN	0.73	0.84	0.63	0.83	0.64	0.83	0.76	0.34
LR	0.76	0.64	0.76	0.64	0.76	0.64	7.86	0.51
NB	0.66	0.41	0.39	0.31	0.40	0.29	0.81	0.12
DT	0.49	0.24	0.26	0.29	0.19	0.20	3.46	0.20
RF	0.66	0.46	0.32	0.40	0.27	0.38	1.82	0.66
SVM	0.73	0.64	0.73	0.63	0.73	0.63	56.94	1.29
CNN	0.86		0.86		0.86		976.19	









1/2	Precision		Recall		F1-Score		Temps	
80/20	Sense	HOG	Sense HOG		Sense HOG		Sense	HOG
KNN	0.75	0.88	0.69	0.88	0.70	0.88	2.09	0.29
LR	0.76	0.66	0.76	0.66	0.76	0.65	13.44	0.83
NB	0.62	0.34	0.41	0.32	0.42	0.32	1.87	0.21
DT	0.50	0.30	0.29	0.28	0.22	0.23	6.83	0.34
RF	0.67	0.45	0.38	0.35	0.34	0.31	3.61	1.17
SVM	0.74	0.67	0.73	0.66	0.73	0.67	145.40	8.30
CNN	0.91		0.91		0.91		2008.67	










Imatges Canny


1/4	Precision		Recall		F1-Score		Temps	
80/20	Sense HOG		Sense	Sense HOG		Sense HOG		HOG
KNN	0.83	0.79	0.52	0.77	0.55	0.78	0.65	0.16
LR	0.64	0.66	0.64	0.65	0.64	0.65	9.19	0.49
NB	0.56	0.23	0.41	0.24	0.40	0.18	0.93	0.20
DT	0.33	0.14	0.25	0.28	0.16	0.16	2.73	0.21
RF	0.55	0.49	0.37	0.37	0.35	0.33	1.57	0.78
SVM	0.69	0.69	0.69	0.68	0.69	0.68	56.36	1.07
CNN	0.85		0.85		0.85		980.47	









1/2	Precision		Recall		F1-Score		Temps	
80/20	Sense HOG		Sense HOG		Sense HOG		Sense	HOG
KNN	0.84	0.84	0.62	0.83	0.65	0.83	2.53	0.48
LR	0.72	0.65	0.72	0.65	0.72	0.65	18.15	1.02
NB	0.59	0.39	0.43	0.28	0.44	0.25	2.91	0.34
DT	0.39	0.21	0.29	0.26	0.24	0.16	8.16	0.61
RF	0.60	0.54	0.32	0.41	0.30	0.36	4.12	1.47
SVM	0.73	0.68	0.73	0.68	0.73	0.68	181.35	7.5
CNN	0.90		0.90		0.90		2291.13	










Imatges Color Filter


1/4	Precision		Recall		F1-Score		Temps	
80/20	Sense HOG		Sense	HOG	Sense HOG		Sense	HOG
KNN	0.73	0.64	0.34	0.34	0.32	0.32	0.71	0.21
LR	0.64	0.60	0.34	0.34	0.32	0.32	10.42	0.37
NB	0.48	0.38	0.29	0.25	0.28	0.21	0.79	0.18
DT	0.43	0.33	0.24	0.24	0.14	0.16	2.03	0.12
RF	0.54	0.43	0.27	0.24	0.21	0.18	1.16	0.39
SVM	0.59	0.55	0.32	0.31	0.29	0.29	55.63	1.16
CNN	0.65		0.35		0.33		950.14	









1/2	Precision		Recall		F1-Score		Temps	
80/20	Sense HOG		Sense HOG		Sense HOG		Sense	HOG
KNN	0.72	0.71	0.34	0.36	0.33	0.35	3.04	0.53
LR	0.74	0.68	0.39	0.36	0.38	0.35	22.12	0.92
NB	0.54	0.44	0.31	0.28	0.28	0.23	2.51	0.28
DT	0.59	0.38	0.24	0.24	0.15	0.15	5.45	0.51
RF	0.51	0.38	0.27	0.26	0.19	0.18	3.19	0.95
SVM	0.69	0.61	0.37	0.34	0.36	0.33	226.04	8.48
CNN	0.73		0.38		0.38		1892.20	










Imatges Otsu


1/4	Precision		Recall		F1-Score		Temps	
80/20	Sense	Sense HOG		Sense HOG		Sense HOG		HOG
KNN	0.89	0.86	0.88	0.86	0.88	0.86	0.77	0.22
LR	0.90	0.70	0.90	0.70	0.90	0.70	6.52	0.51
NB	0.32	0.44	0.26	0.42	0.25	0.42	0.81	0.15
DT	0.36	0.23	0.30	0.26	0.26	0.19	2.76	0.37
RF	0.53	0.51	0.44	0.40	0.41	0.33	1.61	0.59
SVM	0.95	0.72	0.94	0.72	0.94	0.72	36.69	0.88
CNN	0.91		0.91		0.91		976.40	









1/2	Precision		Recall		F1-Score		Temps	
80/20	Sense HOG		Sense HOG		Sense HOG		Sense HOG	
KNN	0.93	0.93	0.93	0.92	0.93	0.92	1.91	0.28
LR	0.92	0.73	0.92	0.73	0.92	0.73	12.07	0.75
NB	0.33	0.46	0.32	0.44	0.31	0.45	1.58	0.15
DT	0.37	0.21	0.29	0.30	0.24	0.23	5.43	0.42
RF	0.55	0.52	0.43	0.40	0.37	0.35	3.27	1.19
SVM	0.97	0.74	0.97	0.74	0.97	0.74	98.71	4.52
CNN	0.93		0.93		0.93		1935.74	







Validació millors resultats

Canvis de percentatges

1/2	Precision		Recall		F1-	Score	Temps	train	Temps	test
KNN	Sense	HOG	Sense	HOG	Sense	HOG	Sense	HOG	Sense	HOG
50/50	0.89	0.88	0.89	0.88	0.88	0.89	0.02	0.014	4.14	0.56
70/30	0.93	0.90	0.93	0.90	0.93	0.90	0.03	0.02	4.34	0.40
80/20	0.93	0.92	0.93	0.92	0.93	0.92	0.04	0.03	3.15	0.35

1/2	Precision		Recall		F1-	Score	Temps	train	Temps	test
SVM	Sense	HOG	Sense	HOG	Sense	HOG	Sense	HOG	Sense	HOG
50/50	0.94	0.70	0.94	0.70	0.94	0.70	51.81	2.17	46.39	1.51
70/30	0.95	0.71	0.95	0.71	0.95	0.71	82.82	4.52	37.35	1.45
80/20	0.95	0.72	0.95	0.72	0.95	0.72	97.00	5.21	25.16	0.95

1/2	Precision	Recall	F1-Score	Temps train	Temps test
CNN	Sense	Sense	Sense	Sense	Sense
50/50	0.90	0.90	0.90	1237.65	5.76
70/30	0.92	0.92	0.92	1739.62	4.13
80/20	0.94	0.94	0.94	2031.17	2.75

